


i-on 40

Security System Installation Guide



CONTENTS

1. Introduction	1
Communications.....	1
Level Setting or Partitioned System.....	1
2. Before You Begin	2
Preparation.....	2
Siting the Unit.....	2
Guided Tour.....	2
Opening the Control Unit Case.....	2
Control Unit PCB.....	3
Keypad Controls and Displays.....	3
Opening the Keypad.....	3
Power Availability.....	4
3. Installation	5
Step 1. Fit the Control Unit Case.....	5
Caution: Static Electricity.....	5
Fitting.....	5
Installing the Lid/Back Tamper.....	5
Step 2. Fit and Connect the Keypad(s).....	5
Siting the Keypad(s).....	5
Fitting.....	6
Connecting Keypads to Control Unit.....	6
Keypad Addressing.....	7
Backlight Control.....	7
Tone Volume.....	7
Step 3. Connect Control Unit to Mains.....	8
Mains Cabling.....	8
Mains Connection.....	8
Step 4. Connect Wired Zones.....	8
Four Wire Closed Circuit Connections.....	8
Fully Supervised Loop Connections.....	8
Step 5. Connect Wired Peripherals.....	9
Remote Loudspeaker (Optional).....	9
Wired External Sounders (Optional).....	9
Wired Outputs (Optional).....	9
Step 6. Fit a Plug-By Communicator.....	10
Step 7. Fit and Connect Battery.....	10
Programming Before Installation.....	11
Step 8. Initial Power-Up.....	11
Step 9. Commission the System.....	12
4. Programming	13
Entering the Installer Menu.....	13
Leaving the Installer Menu.....	13
Important! Saving Changes.....	13
Restoring Access Codes.....	13
Restoring Factory Defaults.....	14
Installer Menu.....	15
Zone Types & Attributes.....	16
Output Types.....	18
Exit Modes.....	21
7. Maintenance	21
8. Technical Specification	22
General.....	22
Capacities.....	22
Security.....	22
Radio.....	22
Power Supply.....	22
EN50131-6 ratings:.....	23
Electromagnetic Compatibility.....	23
Outputs.....	23
Fuses.....	23
Electrical Safety.....	23
Other.....	23
Compliance Statements.....	23
Compatible Equipment.....	24

This page is intentionally blank.

1. Introduction

The i-on40 is the control unit for a hybrid wired/wirefree alarm system intended for domestic and light commercial use.

The control unit comprises an ABS plastic case which contains the radio transceiver, power supply and backup battery. Up to four separate wired keypad(s) can connect to the control unit by standard alarm cable.

The keypads allow end users to set and unset the system, and the installer to configure the control unit. The keypads also contain integral proximity tag readers, allowing end users to control the system without having to remember access codes.

A range of wireless peripherals is available for operation with the control unit. These include a door contact/universal transmitter, a passive infra red detector, smoke detector, external siren, 4 button remote control, and remote radio keypad.

The control unit supports up to 16 wired alarm zones, 24 wirefree alarm zones, up to 16 hardwired outputs, 50 four-button remote controls, 50 two-button radio panic alarms, and 50 users. See page 22.

Communications

The i-on40 provides sockets for an add-on communication module. The available modules are:

- i-sd02 (ATS2) A speech dialler and public switched telephone network (PSTN) module that allows the control unit to send recorded speech messages and report alarm information using standard protocols such as Fast Format, SIA and Contact ID. This module also allows remote maintenance.
- i-dig02 (ATS2) A switched telephone network (PSTN) module that allows the control unit to report alarm information using standard protocols such as Fast Format, SIA and Contact ID. This module also allows remote maintenance.
- i-gsm02 (ATS02) A GSM module that allows alarm reporting, speech messaging and SMS text messaging over the mobile phone network.
- 8750 An Ethernet module that allows alarm reporting and remote

maintenance over the internet.

- 8844 A GPRS module that allows internet protocol access over the mobile phone network.

The control unit also provides outputs that can be used to fit a "plug by" communicator.

To comply with EN50131 you must fit an ATS2 communicator.

Level Setting or Partitioned System

The i-on40 offers two basic ways of behaving as an alarm system:

Part Setting. In a Part Setting system the i-on40 can set in one of four ways: either Full set or three varieties of Part Set. In Full set the control unit pays attention to all detectors. In each of the three Part Sets the control unit ignores detectors that do not have the appropriate Part Set attribute (see page 17).

Partitioned System. In a Partitioned system the i-on40 provides the equivalent of four, smaller, independent alarm systems. Each system is a "Partition" of the i-on40. You can allocate any zone to each Partition. Each zone can also belong to more than one Partition. Each Partition can have a Full Set level and one Part Set Level. During installation the installer can allocate keypads, sounders or outputs to any of the partitions.

This manual shows the simple procedure required to install the control unit and its keypad. When you have completed the physical installation please consult the Programming section for details of configuring the system to meet your exact requirements.

For a detailed description of the Installer's programming menu please read *i-on40 Programming Reference Guide* available from www.coopersecurity.co.uk.

Note: Some programming options can make the installation non-compliant with EN50131. The relevant options are noted in Appendix 1 of the i-on40 Programming Reference manual.

2. Before You Begin

Preparation

Before installation you should carry out a survey of the site. You need to know how many and what kind of detectors will be transmitting to the control unit. You also need to assess where the control unit must be placed in order to receive radio signals from the detectors successfully.

To do this you should conduct signal strength tests. Cooper Security produce the Scantronic 790r hand held signal strength meter for this purpose. Alternatively, you can power the control unit from a battery and use its built-in testing facility to measure the signal strength from a detector that you temporarily place at each planned location.

Siting the Unit

Do site the unit:

Upright (battery at the bottom).
Within a protected zone.

As high as possible. However, do make sure that the unit is on a similar level to the other transmitters or receivers.

Do NOT site the unit:

In the entry or exit zones, or outside the area covered by the alarm system.
Close to or on large metal structures.
Closer than one metre to mains wiring, metal water or gas pipes, or other metal surfaces.

Lower than two metres from the floor (ideally).

Inside metal enclosures.

Next to electronic equipment, particularly computers, photocopiers or other radio equipment, CAT 5 data lines or industrial mains equipment.

Note: Some window glasses, especially those sold as "insulating" or "energy conserving" may be coated with thin metal or conducting films. These glasses are particularly poor at transmitting radio waves.

If fitting two or more keypads make sure that you do not place the keypads within one metre to each other. (The proximity tag readers in each keypad will interfere with each other.) Remember not to place keypads on opposite sides of the same wall.

Guided Tour

Opening the Control Unit Case

To gain access to the interior of the control unit undo the two screws at the top of the case. Pull the top of the lid down, and then lift the lid out of the retaining lugs at the bottom of the case.




Figure 1 Opening the Control Unit.

WARNING: When connected to the mains with power applied mains voltages are present on the shrouded heads of the terminal screws of the mains connector ("8" in figure 1).




Figure 2 Control Unit

1. Central fixing keyhole.
2. Aerials.
3. Fixing holes.
4. Connector pins for Lid Tamper.

5. Printed circuit board (PCB).
6. Cable entry holes for detector and keypad wiring.
7. Transformer.
8. Mains connector block. Note yellow power rating label fitted next to the connector block.
9. Cable entry hole for mains.
10. Back Tamper switch (if fitted).

Control Unit PCB




Figure 3 Control Unit Printed Circuit Board

1. Aerials (**CAUTION: do not bend**).
2. Tamper connector.
3. USB socket (Mini B).
4. Ethernet link activity LEDs.
5. 20VAC input (from transformer).
6. Battery connector.
7. Kick Start pins.
8. Ethernet socket.
9. "Heartbeat" LED
10. RS485 terminator.
11. Code reset pins.
12. Plug by connector pins 13-16.
13. Plug by connector pins 1 to 12.
14. Comms activity LED.
15. Sockets for plug on module.




Figure 4 Control Unit Main Connectors

1. Aux power.
2. Outputs (relay).
3. Aux power.
4. Keypad bus.
5. Wired zone connectors.
6. Ethernet connector.
7. Loudspeaker.
8. Wired siren tamper return.

9. Outputs (transistorised).
10. 14.4V Siren supply (not used in UK).

Keypad Controls and Displays




Figure 5 Controls and Displays

1. LCD display (2 x 20 characters).
2. Programming keys.
3. Navigation keys
4. Alert LEDs
5. Setting and unsetting keys.
6. Panic Alarm (PA) keys.
7. Number/text keys.
8. Set/Unset LEDs.

Opening the Keypad

Note: For EN50131-3:2009, 8.7 the keypad is a type B ACE, fixed.

To open the keypad first gently prise off the trim on the front and remove the two screws. Next, carefully lever the front of the keypad (containing the pcb and display) away from the keypad rear housing.




Figure 6 Opening the Keypad




Figure 7 Keypad Rear Housing

1. Central keyhole.
2. Rear tamper shroud.
3. Cable entry.
4. Fixing holes.




Figure 8 Keypad PCB

1. Sounder.
2. Sounder volume control.
3. Tamper switch.
4. Jumpers for addressing and LED function:
 - 4a Addressing
 - 4b LED functions
5. RS485 termination jumper
6. Connector for control unit (note that the ET terminals are inactive).

Power Availability

Before connecting any external devices to the control unit, you must make sure that the control unit can provide sufficient current to power the system during a mains failure for the time required to meet Grade 2 PD6662 or EN50131-1. The standard requires 12 hour standby, which includes two periods of 15 mins in alarm.

The amount of current available from the control unit depends on the battery fitted. The current taken by the control unit pcb, communicator and keypads is given in Technical Specifications on page 22.

For example: in an alarm system with an i-on40 control unit, two i-kp01 keypads, and 15 wired PIRs the system takes the following total quiescent current:

Device	Current
Control unit PCB	130mA
15 x PIRs at 15mA each	225mA
i-sd02 communicator (quiescent)	20mA
2 x i-kp01 at 30mA each (backlights off)	60mA
Siren (quiescent)	25mA
Total	460mA

During an alarm, these figures become:

Device	Current
Control unit PCB	220mA
15 x PIRs at 15mA each	225mA
i-sd02 communicator	50mA
2 x i-kp01 at 30mA each (backlights off)	60mA
Ext Siren & Strobe	400mA
Total	955mA

The total amp hours required =
 $(0.460A \times 11.5h) + (0.955A \times 0.5h) = 5.77Ah$

A fully charged 7Ah battery can provide this amount of charge.

In this example a 7Ah battery should exceed the Grade 2 requirements.

Note: All current drawn from the Aux terminals (12V and 14.4V) must be included in the overall calculation..

3. Installation

Exposure to Radio Frequency Radiation

The radiated output power of this device is below those levels considered safe by European exposure limits. Nevertheless, when fitting the product place it in such a manner as to minimise the potential for human contact during normal operation. To minimise exposure, users should be more than 200 mm from the device during normal operation

Step 1. Fit the Control Unit Case

Caution: Static Electricity

Like many other electronic products, the control unit contains components that are sensitive to static electricity. Try not handle the PCB directly. If you must handle the PCB, take the standard precautions against damage by static electricity.

Fitting




Figure 9 Fixing Holes and Cable Entries

1. Fixing holes.
2. Cable entries.

To prevent access to the inside of the control unit, you must mount the back of

the control unit on a wall, using at least four fixing holes. Use No10/M5 countersunk screws at least 36mm long. Figure 9 shows the fixing holes and cable entries.

Protect the unit from dust and drilling debris when drilling the fixing holes.

Installing the Lid/Back Tamper

Fit and connect the combined lid/back tamper (provided). Ensure that the switch is oriented as shown in Figure 10.




Figure 10 Lid/Back Tamper

Item 2 in Figure 3 shows the connector for the lid/back tamper.

Step 2. Fit and Connect the Keypad(s)

Siting the Keypad(s)

Do site the keypad(s):

Within the area protected by the alarm system.

At a convenient height and location for the user.

Out of sight of potential intruders.

Do NOT site the keypad(s):

Next to electronic equipment, particularly computers, photocopiers or other radio equipment, CAT 5 data lines or industrial mains equipment.

Where the cable run from the control unit will be longer than 100m (see Cable Configuration and Length).

Note: Do not site two or more keypads closer than one metre together, otherwise their prox readers will interfere and be unable to read tags.

Fitting

Use M4 25mm countersunk screws in at least three fixing holes when mounting the back of the keypad on the wall.




Figure 11 Screw Keypad Back Box to Wall

Connecting Keypads to Control Unit

Cable Type

In general, the control unit requires standard 7/0.2 un-screened four core alarm cable for wiring to keypads.

For maximum performance in harsh environments use twisted pair cable with a characteristic impedance of 100-120ohms eg: CAT5 or cable designed for RS485.

Use one pair for data bus A & B. Use the other pair for 12V & 0V. For optimum performance the voltage at the keypad should be greater than 12V.

Screened cable may prove necessary if the installation site has equipment that produces high levels of R.F. (Radio Frequencies), for example welding equipment. If screened cable is required, you should keep to the following guidelines:

1. Avoid earth loops by connecting the screen on the cable to mains earth at the control unit but not at the keypad.
2. The continuity of the cable screen is most important and screens MUST be continuous along the full length of the cable.
3. If the cable enters any metal enclosure, ensure the screen is isolated from the case.

Cable Segregation

Segregate the keypad cabling from any other wiring, such as mains supply cables, telephone cables, computer network cables

and R.F. cables. Use cable ties to keep cables separated.

Keep the keypad cable clear of cables supplying sounders or extension loudspeakers.

Cable Configuration and Length

You can connect up to four wired keypads to the control unit. You may connect the keypads either in daisy chain (serially), or in star (parallel) configuration at the control unit connector.




Figure 12 Keypad Wiring Configurations

For star configurations the cable length from control unit to the most distant keypad should not exceed 100m. For a daisy chain configuration the total cable length should not exceed 250m,

Connection

Figure 13 shows the wiring connections at the keypad and control unit.




Figure 13 Keypad Connection

Termination

The i-on40 data bus uses the RS485 interface. Because of this the ends of the line in some configurations may be terminated to improve performance in electrically noisy environments or where there are long cable runs. Both control panel and keypads have a termination link on their PCBs (see 10 in Fig 3 for the control unit and 5 in Fig 8 for the keypad). Fitting a jumper to the pins adds a termination to the cable.

In a daisy chain configuration terminate each end of the chain (see Fig 12).

In a star configuration:

If there are only two keypads then this is the same as a daisy chain configuration. If required terminate at each keypad.

If there are more than two keypads AND two cables are long while the remaining keypad cables are short (less than 10m) then it is possible to terminate at the two keypads with long cables.

If there are more than two keypads BUT each keypad cable is more than 10m then **DO NOT** terminate.

Keypad Addressing

Each keypad connected to an control unit must have a unique address. See Figure 8 on page 4 for the position of the addressing jumpers.




Figure 14 Keypad Addressing Jumpers

Backlight Control

You can control the appearance of the keypad backlights and set/unset LEDs by fitting links over the appropriate jumpers

on the keypad pcb (see Figure 8 on page 4 for the position of the jumpers).

The jumpers have the following functions:

ABCD-ON

The set/unset LEDs are disabled.

ABCD-ON

The set/unset LEDs shows the setting status of the system. (Full set is left hand led.)

BL⁻ ON
BL⁻ BRIGHT

The key backlights are disabled. They will glow briefly for five seconds when a user presses a key.

BL⁻ ON
BL⁻ BRIGHT

The key backlights glow all the time at normal intensity.

BL⁻ ON
BL⁻ BRIGHT

The keypad backlights glow all the time, extra bright.

Tone Volume

To alter the volume of non-alarm tones from the keypad adjust the keypad sounder volume control (2 in Fig 8):

Louder

Note: This control changes the volume of non-alarm tones (for example Exit/Entry tone). The volume of alarm tones is fixed.

Softer

Step 3. Connect Control Unit to Mains

WARNING: ENSURE THAT THE MAIN SUPPLY IS DISCONNECTED AND ISOLATED BEFORE MAKING ANY MAINS CONNECTIONS. All mains electrical connections must be carried out by a qualified electrician and must comply with the current local regulations (e.g. IEE).

Mains Cabling

Make sure that the mains supply cable does not run vertically behind the aerials within the control unit case.

If you wish run mains cable through the side of the case, make sure that they are horizontal for the last metre before entering the case.




Figure 15 Mains Cabling Clearance

Note: To avoid mains interference, the mains cable must enter the control unit through its own cable entry hole (9 in Fig 2) and must not be mixed with other cables.

Mains Connection

Figure 16 shows the mains connection. Connect to a suitable supply using a double pole disconnect device in accordance with EN60950-1.

Caution: Do not apply power at this point.

Anchor the mains cable with a strain-relief tie. There is an eye located near the mains cable entry hole for this purpose.




Figure 16 Mains Connection

Step 4. Connect Wired Zones

Four Wire Closed Circuit Connections




Figure 17 Closed Circuit Loop Zone Wiring

Fully Supervised Loop Connections

Figure 18 shows the wiring connections for Fully Supervised Loop zones. Note that the resistance values shown are examples.

The allowed values for Alarm Contact/End of Line are: 4k7/2k2, 1k0/1k0, 2k2/2k2, or 4k7/4k7.

Use the same pair of values for ALL FSL wired zone circuits.

When programming select the correspondings value in *Installer Menu - System Options - Wired Zone Type*

If you wish to connect two or more detectors to a FSL zone, the diagram at the bottom of Figure 18 shows the connections required.

Figure 19 shows an example of wiring double doors with two door contacts to one

FSL zone. Each door contact is a reed switch, connected between the outer terminals. The inner (shaded) terminal is not connected, and provides a spare terminal.




Figure 18 Fully Supervised Loop Zone Wiring




Figure 19 Example: Wiring Two Door Contacts to One FSL Zone.

Step 5. Connect Wired Peripherals




Figure 20 Connecting Wired Peripherals

The control unit pcb provides four connectors for wired outputs. Outputs 1 and 2 are voltage free relay outputs. Outputs 3 and 4 are driven by transistors, and are capable of sinking a maximum 500mA when active. By default outputs 3 and 4 are 0V when active, +12V when inactive. If you wish to reverse the polarity of these two outputs use *Installer Menu - Outputs - Wired Outputs - Output 3(4) - Polarity*.

Remote Loudspeaker (Optional)

If you wish to add a wired Loudspeaker unit, then connect it as shown in Figure 20.

Wired External Sounders (Optional)

Wired external sounders differ in their methods of connection. Figure 20 shows an example of a general method of using the outputs to connect a wired sounder.

Note: If you do not wish to connect a wired external sounder then make sure you link TR to 0V. This prevents the control unit reporting Bell Tamper unnecessarily.


Wired Outputs (Optional)

Figure 20 shows an example of using the wired outputs to drive an indicator LED.

Step 6. Fit a Plug-By Communicator

The control unit can be connected to a separate communicator or speech dialler (for example, the Scantronic 8400, 8440, 660 or RedCare STU). Figure 21 shows the connections provided by the communications wiring harness.

Com Connector Cable,
Part number 485210



Com Connector Cable,
Part number 11960058




Figure 21 Plug-By Communicator Wiring

Note: Comms O/P4 will be active when the system is unset. This is normal.

To fit a communicator, follow the instructions below.

Caution: Follow the instructions in the order shown, or you may damage the control unit and/or communicator.

1. Disconnect mains power, remove the case lid, and disconnect the battery from the control unit if the system has already been installed.
2. Make any necessary connections from the communicator to the communication wiring harness. The default is a 12V positive voltage when the output is inactive.

Refer to the next section if you are using a dual-path communicator.

3. Plug the Communication Wiring Harness onto the communications connector on the main PCB.

If the system has already been installed:

4. Re-connect the battery.
5. Fit the case lid.
6. Apply mains power.
7. Test communicator operation.

Line Monitoring for a Dual-Path Communicator

If a standalone dual-path (landline and mobile) communication device, such as a RedCARE STU, is connected to the plug-by connector, you need to do the following to obtain correct line fault reporting (this is not necessary if you are using a plug-on module):

1. Wire a panel output programmed as type "ATS Test" to the ATS Test input of the communicator.
2. Wire the Line Fault output of the communicator to the Line Fault input of the plug-by connector. The communicator must provide +12Vdc to indicate a line fault (for example, if the Line Fault output at the communicator uses a relay, connect the common terminal of the relay to +12Vdc and the normally-open terminal to the Line Fault input of the plug-by connector).

The panel will generate an "ATE L.F. Single" alert if only one of the networks is not available, or "ATE L.F. All" if both networks are not available.

Step 7. Fit and Connect Battery

Fit a 7Ah Lead Acid battery into the battery compartment in the bottom of the control unit, see Figure 22.

Make sure that you secure the battery to the case with the strap provided. Connect the battery leads, red to the positive, black to the negative terminals of the battery.




Figure 22 Fitting the Battery

Note: Connecting the battery without mains power will not start the system. (See "Programming A Control Unit Before Installation" below if you wish to start the system on battery power.)

Programming Before Installation

If you prefer, you can make the control unit learn the detectors and other peripherals before installing the system in its final location. You will need to temporarily connect a keypad to the control unit.

It is possible to operate the control unit from battery power (or a 12Vdc supply) without connecting the unit to a mains supply. However, in order to start the control unit processor running you must briefly short the Kick Start pins together after connecting the battery.

When programming the system while it is running on battery only, remember to leave the Installer Menu before removing power. If you do not do so all your changes will be lost, see *Important! Saving Changes* on page 13

If you wish to program the control unit from a laptop or PC you can do this by connecting the control unit to your PC via Ethernet. You will need a CAT 5 patch cable and a laptop or PC with a standard web browser. See the separate publication *i-on40 Web Server Set Up Guide* for instructions on how to set up your PC/laptop and the control unit.

Step 8. Initial Power-Up

WARNING: During initial power-up all the keypad sounders and any internal loudspeaker MAY give an alarm tone. If you are working at the top of a ladder make sure that the sudden noise does not startle you and cause a fall.

- 1. Apply battery then mains power to the control unit.

The keypads and internal sounder may give an alarm tone. The heartbeat LED (see fig 3) starts flashing.

The display initially shows:

Language?
English

- 2. Press ▲ or ▼ to show other languages on the bottom line of the display. for example:

Language?
Nederlands

- 3. Press ✓ to select the language you want.

From this point on, the display operates in the selected language. If you want to change the language later use *Installer Menu - System Options - Language*.

The display shows:

COUNTRY DEFAULTS
*UK

- 4. Press ▲ or ▼ to show other countries, for example:

COUNTRY DEFAULTS
Italy

- 5. Press ✓ to select the country you want.

The display shows:

A : Partition mode
B : Part set mode

- 6. Press A or B to select either a partitioned system or a Part Setting system.

The display shows:

Load Profile?

- 7. Either: Press ✓ to load the Profile.

Or: Press ✕ to start with a blank system

Note: Profiles may not be EN50131 compliant. Please check the *i-on40* web page on www.coopersecurity.co.uk for a list of the available profiles. (The factory default is EN50131 compliant.)

The control unit loads your choice of profile, and then shows:

WIRED_ZONE_TYPE
*2-wire FSL 2k2/4k7

- 8. Press ▲ or ▼ to show the range of wiring types available, for example:

WIRED_ZONE_TYPE
4-wire CC

- 9. Press ✓ to select the wiring type you intend to use for the wired zones

The display shows:

INSTALLER_EXIT_FLTS
Panel lid open

Note that the alert LEDs round the navigation glow red. This is because the control unit lid is off and the tamper is active.

- 10. Press ✕.

The display shows:

INSTALLER MENU
Detectors/Devices

At this point you can carry on to commission the system. See the next page.

Note: Setting the time and date is an administrative user function. See *i-on40 Administrator's Guide* for instructions.

Step 9. Commission the System

After installing the control unit you should commission the alarm system as follows:

1. Use the Installer Menu (see Chapter 4) to teach the control unit the identity of its radio detectors and any other peripherals. See the installation instructions supplied with each detector or peripheral.
2. Install detectors and peripherals at their selected locations.
3. Use the *Installer Menu – Test* (see Chapter 5) option to:
 - a) carry out a walk test of the detectors.
 - b) test the operation of any other peripherals.
4. Program the system to suit user requirements. See the *i-on40 Programming Reference* for a detailed description of the Installer Menu.
5. Assemble and close the control unit:
 - a) Hook the lid of the control unit into the bottom of the case.
 - b) Close the lid and then tighten the two fixing screws.




Figure 23 Replacing the control unit lid.

6. Leave the Installer Menu.

The red LEDs should go out, and the rim of the navigation keys glow green. The system is now ready to hand over to the user.
7. Instruct the user on how to operate the system. See the *i-on40 User Guide* and the *i-on40 Administrator's Guide*. If necessary, show them how to set the time and date on the system.

Note that you can obtain the Administrator's Guide from www.coopersecurity.co.uk.

4. Programming

This section is summary of the Installer Menu on the i-on40. Please see the *i-on40 Programming Reference* for a more detailed description.

Entering the Installer Menu

1. Make sure the system is unset and showing the standby screen (time and date).
2. Key in the Installer access code. When delivered from the factory the default Installer access code is "7890". The default user code is "1234".

As you start to key in the code the display shows:

```
Enter Access Code:
(*)
```

When you key in the last digit of the Installer access code the display shows:

```
User Code Required
{ }
```

Note: You will see this screen the first time you enter the Installer menu on a new control unit, or if you have restored Factory Defaults.

3. Key in the default user code (see Note below).
The display shows:

```
Installer Menu
Detectors/Devices>
```

4. Press ▲ or ▼ to display more items from the menu.
Each item appears on the bottom line of the display in turn, for example:

```
Installer Menu
Outputs >
```

5. Press ► to select that item of the menu.
The option you selected now appears on the top line. If there are any sub-options for that selection, then the first of them appears on the bottom line, for example:

```
Outputs
Edit Outputs >
```

You can press ▲ or ▼ to display the other sub-options.

Note: If you key in an access code incorrectly, the display shows four "stars". Key in the code again. If you key in a total of ten incorrect codes then the system locks you out for 90 seconds.

Leaving the Installer Menu

If you wish to leave the Installer Menu at any time.

1. Press ✕ until the display shows the words "Leave installer mode?".

```
Leave
installer mode?
```

2. Press ✓ to leave Installer menu. (Press ✕ if you do not want to leave the menu.)

The display shows the time and date.

```
i-on40
12:00 02/01/2008
```

The system is ready for use.

Note: If you attempt to leave the Installer Menu when a detector tamper is active then the keypad displays a fault message telling you which detector is causing the problem.

Press ✕ to return to the Installer Menu. You must either close the detector tamper or delete it from the system before you can leave the Installer Menu.

Important! Saving Changes

When you make changes to the Installer Menu the control unit holds those changes in temporary memory until you leave the Installer Menu. As you leave the Installer Menu the control unit writes those changes into a permanent store. If you remove all power BEFORE you leave the Installer Menu then the control unit will lose your changes. Note that this does not apply if you restore Factory Defaults, that change takes place immediately.

Restoring Access Codes

If the user and/or Installer codes are lost then ;

1. If possible, enter the Installer menu.
Note: If you cannot enter Installer Menu then the control unit will start a tamper alarm when you open the control unit lid.
2. Remove mains power, then open the case and disconnect the battery.

Note: This procedure will not work if the control unit lid tamper remains closed.

3. Identify the Reset Codes pins on the main PCB (see Figure 3).

4. Short the Reset Codes pins together using a screwdriver or jumper link. (Keep the short on until step 6.)
5. Apply mains power.
The control unit loads the factory default access codes:
User 1: 1234, Installer: 7890.
(All other users have been deleted.)
After a short pause the keypad display shows the time and date. The red LEDs glow to show an alert that the panel lid is open. **The sounders operate.**
6. Remove the short from the Reset Codes pins.
7. Reconnect the battery.
8. Close the control unit lid (to restore the tamper switch).
9. Key in the Master User code, 1234, to silence the sirens.
The LEDs around the navigation glow red to show an alert for a tamper and a missing battery.
Press ✓ twice to (if necessary) acknowledge any alerts.
To force the control unit to check the battery:
10. Enter Installer Menu and then leave it again.
The navigation key LEDs should now glow green.

Note: The log is protected and cannot be erased by the Installer.

Restoring Factory Defaults

If you wish to restore all factory default options then:

1. From the Installer Menu select *System Options – Restore Defaults – Factory Defaults*.
The display asks for confirmation.
2. Press ✓ to load defaults.
(Press ✕ to go back to the Installer Menu without changing defaults.)
The display asks you to select Partition Mode or Part Set Mode.
3. Press A or B to select the desired mode.
The display asks you to select the zone wiring type.

4. Press ▲ or ▼ to display the desired wiring type on the bottom line of the display and then press ✓ to select it.
The system loads all defaults except for Access Codes and the Log.

The display shows:

Factory defaults
restored

5. Leave the Installer Menu to save the change (press ✕ until the display shows "Leave Installer mode ?" then press ✓).

Installer Menu

1 DETECTORS/ DEVICES

Detectors

Add/Del Detectors
Zone 17...40
Delete all
Edit Zones
Zone 01...40
Name
Type
Partitions¹
Attributes⁵

Wired Keypads

Keypad 01...04
Name
Partitions¹
Key A...B¹

Radio Keypads

Add/Del Radio Keypad
Edit Keypads
Name
Partitions¹
Key A...B¹

External Sirens

Add/Delete Ext. Siren
Edit external siren

Info Modules

Teach Info Module
Updates
Ready-to-set LED

WAMs

Add/Del WAM
View WAM

2 OUTPUTS

Radio outputs

Add Outputs
Edit Outputs
Output 01...08
Name
Type

Wired outputs

Output 1...4
Name
Type
Polarity
Partitions*

Plug-by outputs

Output 1...12
Name
Type
Polarity
Partitions*

3 SETTING OPTIONS²

Full Set

Name
Exit mode
Settle time⁹
Exit time¹⁰
Entry time
Strobe on Set
Strobe on Unset

Part Set B

Name
Exit Mode
Settle time⁹
Exit time¹⁰
Entry time
Alarm Response
Part Set Final Exit
Part Set Entry Route
Strobe on Set
Strobe on Unset

Part C, D

(See Part Set B)

3 PARTITIONS¹

Partition 1...4

Name
Exit Mode
Settle Time⁹
Exit Time¹⁰
Entry Time
Alarm Response
Strobe on Set
Strobe on Unset
Part Set Exit Mode⁹
Part Set Settle Time⁹
Part Set Exit Time¹⁰
Part Set Entry Time
Part Set Alarm
Response
Part Set Final Exit
Part Set Entry Route
Part Set Strobe Set
Part Set Strobe Unset

Partition 2...4

Full Set Link

4 SYSTEM OPTIONS

Wired Zone type

User Access
PA keys active
Quick Set
Quick Omit
User code reqd

User reset

Zone alarms⁷
Zone tampers
System tampers

DD243

Confirmation
Confirmation time
After Entry
Entry Keypad Lock
Sounder on
Siren on
Unconfirmed reset
Confirmed reset

Profiles

Language

Restore Defaults

Installer Name

Installer Code

Keypad text

Remote Needs Entry

PA Response

Auto Rearm⁷

Siren Delay

Siren Time

Loudspeaker Volume

Entry Alarm Delay

Supervision

Jamming

Force Set

Tamper Omit

CSID Code

Silence Alerts

Mains Fail Delay

5 COMMUNICATIONS

ARC Reporting⁵

Call Mode
Phone book
IP Network⁵
Account Number
Report Type
Fast Format channels³
CID/SIA Events⁴
Restorals⁴
Burg Comms Rearm³
21CN FF Ack time³
Send tamper as burg⁴
Dynamic Test Call
Static Test Call
Speech Dialler⁵
Call Mode
Messages
Phone Book

Triggers
Destinations
Call Acknowledge

SMS⁵

Call Mode
Messages
Phone Book
Triggers

Line Fail Response⁵

Line Fail Delay⁵

IP Network (Own)

Web Server
GPRS⁵
Ethernet⁵

Downloading

Account
Connection Type
Rings to Answer⁵
Answer on one ring⁵
Access Mode⁵
Phone Book⁵
Secure Callback⁵
Modem Baud Rate⁵

6 TEST

Sirens & Sounders

Wired Keypad

Walk Test

Zone Resistances

Signal Strengths

Detectors
Radio Keypads
External Sirens
WAMs

Outputs

Radio Outputs
Wired Outputs
Plug-by outputs

Remotes

Panic Alarms

Prox Tags

ARC Reporting

Speech Dialler⁵

PSU Current

7 VIEW LOG

8 ABOUT

Panel

Comms

Panel Ethernet

¹Appears only in a Partitioned system (or when zones have a type other than "Not Used".

²Appears only in a Level Setting system.

³Appears only when Report Type=Fast Format

⁴Appears when Report Type=CID or SIA

⁵Options visible depend on communications module fitted.

⁶Appears when zone is given a type other than "Not Used".

⁷Appears only when System Options – DD243 – Confirmation is "off".

⁸Appears only when device learned in.

⁹Appears only if Exit Mode is "Final Door".

¹⁰Appears only if Exit Mode is "Timed Exit" or "Silent Set".

Zone Types & Attributes

(Hint: You can select a zone type quickly by keying the number shown in brackets after the type's name, for example: "05" to select Alarm Abort, "02" to select Panic Alarm, "11" to select External PSU A/C Fail. The number does not appear on the keypad display.)

Not Used (00)

The alarm system will not respond when an event triggers this detector.

Panic Alarm (01).

Operating a device programmed as 'Panic Alarm' (PA) will start an audible alarm. If a communications module is fitted there may also be an alarm transmission to the Alarm Receiving Centre (ARC), depending on how you have programmed the ARC Reporting option. PA alarms operate whether the system is set or unset.

Fire Alarm (02).

Smoke or heat detectors connected to Fire Alarm zones cause the sirens to give a pulsing fire signal. Fire alarms operate whether the system is set or unset, and will always trigger communications, if a communications module is fitted and enabled.

Normal Alarm (03).

A zone programmed as 'Normal Alarm' will start an alarm when the system is set. (See "Zone Attributes" on page 17.)

24 Hour Alarm (04).

Activating this zone causes an alarm whether the system is set or unset.

Final Exit (05).

Zones of this type must be the last detector to be activated on exit, or the first to be activated on entry. You can use zones of this type to finally set the system, or to start the entry procedure.

Note: If you give a Final Exit zone any of the Part Set attributes then you can program that zone to behave like a Normal Alarm zone if the user part sets the system.

Entry Route (06).

Use this zone type for detectors sited between the Final Exit door/detector and the keypad. If an 'Entry Route'

zone is triggered when the system is set, an alarm will occur. If the entry/exit timer is running when an Entry Route zone is triggered then no alarm occurs until the entry/exit timer expires.

Note: If you give an Entry Route zone one of the Part Set attributes then you can program that zone to behave like a Final Exit zone if the user part sets the system.

Technical Alarm (07).

Use this zone type when you want to monitor equipment, for example a freezer, without raising a full alarm. If a technical alarm zone is activated (and the control unit correctly programmed) then the control unit starts communication and logs the event.

If the technical alarm occurs while the system is set, then system makes no audible alarm. When a user unsets the system the keypad shows an alert.

If a technical alarm zone is activated while the system is unset then the system starts an alert immediately and gives a brief tone from the keypad every few seconds. When a user enters a valid access code the keypad stops the tone and displays the zone causing the alarm.

When the user acknowledges the alert by pressing ✓ the control unit resets the technical alarm ready for the next event.

Key Switch Momentary (08).

Note: The use of a keyswitch is not compatible with EN50131-1. This is because the system restore activation (on the keypad) does not require a level 2 user code.

Use this zone type to connect a momentary keyswitch to a single zone.

In a Part Setting system the keyswitch can Full Set or unset.

In a Partitioned system you can allocate the keyswitch to one or more partitions.

Each time a user operates the keyswitch the control unit changes the current set state.

Key Switch Latched (09).

Use this zone type to connect a fixed position keyswitch to a single zone. In a Part Setting system the keyswitch can Full Set or unset. As with Momentary keyswitches, you can allocate the zone to one or more Partitions (see above). When the user closes the keyswitch contacts the control unit sets the allocated Partition. When the user opens the contacts the control unit unsets the allocated Partition.

Notes:

1. *The keyswitch zone types are intended for use on zones that connect to an access control keypad, electronic key or other type of hardwired device used to set or unset the system.*
2. *When the user operates the keyswitch while the system is unset then the control unit starts the programmed exit mode.*
3. *When the user operates the keyswitch while the system is set then the control unit unsets the system immediately.*
4. *The user cannot reset the system from a Keyswitch zone.*
5. *Do not assign more than one Latched Key Switch zone to a partition.*

Tamper (10)

Use this zone type to monitor the tamper status of external equipment. The control unit monitors a Tamper zone at all times. When triggered in the unset condition, only internal sounders operate. When triggered in the set condition, the alarm response determines whether external sounders, strobe and communications also respond to the alarm.

External PSU A/C Fail (11)

Use this zone type to monitor the A/C Fail output of an external power supply unit. If a power supply unit triggers a zone with this type then the control unit waits for a random time between 52 and 59 minutes before activating any output programmed as 'AC Fail' and causes an alert that displays 'External mains fail' on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

External PSU Battery Fault (12)

Use this zone type to monitor the Battery Fault output of an external power supply unit. If an external PSU triggers a zone with this type then the control unit activates any output programmed as 'Battery Fault' and causes an alert that displays 'External Battery Fault' on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

External PSU Low Volts (13).

Use this zone type to monitor the Low Battery output of an external power supply unit. If a power supply triggers a zone with this type then the control unit activates any output programmed as 'Low Battery' and causes an alert that displays 'External Low Battery' on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

External PSU Fault (14).

Use this zone type to monitor the fault output of an external PSU. If a power supply triggers a zone with this type then the control unit activates any output programmed as 'External PSU Fault' and causes an alert that displays 'External power fault' on the keypad.

If the alarm system is set then the control unit logs the event, starts any programmed communication, but does not start an alarm.

Zone Attributes

Note: a) This menu does not appear if a zone has the type 'Not Used'. b) Some attributes are not available for certain zone types. The display shows the available attributes for the zone type you select.

Chime

When enabled by the user, the system gives a non-alarm warning tone when any zones programmed as 'Chime' are opened. This facility operates only while the system is unset.

Soak Test

Use this zone attribute if you want to place under long term test a detector that you suspect is giving false

alarms. Zones with this attribute are disabled for 14 days after you return the control unit to user/unset mode. If the zone remains inactive for the whole fourteen days then after midnight on the 14th day the control unit returns the zone to normal use. If the zone is activated during those 14 days while the system is set then the control unit logs the event as a "Soak Test Fail Zn" (n is the zone number) without sounding any sirens or starting communications. The control unit also lights the red LEDs around the navigation key on the keypad to alert the user. You can apply the soak test attribute to Normal Alarm, Entry Route and Tamper zone types.

Double Knock

Zones programmed with this attribute will cause an alarm only if the zone is EITHER triggered, restored and triggered again within a five minute period, OR if the zone remains active for 10 seconds.

You can apply the Double Knock attribute to the Normal Alarm and Entry Route zone types.

Part Set B

(Not visible in a partitioned system.) When a user presses button B (part set), the control unit sets only those zones where the Part Set B attribute = "Yes".

Part Set C

(Not visible in a partitioned system.) When a user presses button C the control unit sets only those zones where Part Set C attribute = "Yes".

Part Set D

(Not visible in a partitioned system.) When a user presses button D the control unit sets only those zones where Part Set D attribute = "Yes".

Part Set

(Not visible in a Part Setting system.) When a partition is Part Set, zones in that partition with this attribute are set. Note that if a zone is in more than one partition, all partitions have to be set or part set before this zone will be set.

Omittable

This attribute applies to Normal Alarm, 24hr and Technical zone types only.

A) When a zone has this attribute, a user can omit it before setting the system.

B) If a user tries to set the system when a zone with this attribute is open (active) the control unit alerts them and pauses the setting procedure. The user can acknowledge the alert by pressing ✓ and continue setting. You must enable this feature in the *System Options – User Access – Quick Omit* menu.

Force Set Omit

When this attribute is set to Yes a user with a remote control can set the system while the zone is open (active). (You must enable this feature in the *System Options – Force Set* menu.)

Output Types

You can select an output type quickly by keying the number shown in brackets after the type's name, for example: "04" to select Open/Close, "02" to select Panic Alarm, "19" to select General Fault. (The number does not appear on the keypad display.)

With Normal polarity a transistorised output applies 0V when active and +12V when inactive. With Inverted polarity the output applies +12V when active.

Type:	Active when:
Not Used (00)	(Never)
Fire Alarm (01)	The control unit starts a fire alarm.
Panic Alarm (02)	The control unit starts a panic alarm.
Burglar Alarm (03)	Any of the following zones are triggered: Normal Alarm Tamper (in a set system) Entry Route Tamper Zone (in a set system) Entry time expires 24 hour (in a set system)
Open/Close (04)	The system is unset. Inactive when the system is set.
Alarm Abort (05)	An alarm in the selected partition has been aborted by the user within the 90s abort period. Deactivates when the alarm is reset.

Type:	Active when:
Technical Alarm (06)	There is a technical alarm.
Confirmed Alarm (07)	There is a confirmed alarm. Deactivates when the system is reset.
RF Low Battery (08)	A wirefree detector reports a low battery. The output remains active until all detectors stop reporting low batteries.
RF Supervision (09)	There is a supervision failure on any radio zone. The output remains active until all supervision failures are reset.
RF Jamming (10)	The control unit detects jamming. The output remains on until all jamming disappears.
RF Fault (11)	There are any of the following faults: RF Low Battery, RF supervision, RF jamming.
Panel A/C Fail (12)	Either Mains power is absent for between 52 and 59 minutes, OR a zone of type "External PSU A/C Fail" has been triggered. The control unit deactivates the output if a user keys in a valid access code after mains power has been restored.
Panel Battery Fault (13)	The control unit detects a fault with its backup battery, OR a zone of type "External PSU Battery Fault" has been triggered. If the alert was caused by an "External PSU Battery Fault" zone then the control unit deactivates the output when the zone has been restored and a user has acknowledges the fault by entering a valid access code. If the alert was caused by a fault with the control unit's backup battery then the control unit deactivates the output when it detects a good battery and a user acknowledges the alert. <i>Note: To cause the control unit to check its backup battery enter and leave the Installer Menu.</i>
External PSU Low	An external power supply has triggered an External PSU Low

Type:	Active when:
Volts (14)	Volts zone. The control unit deactivates the output when the zone has been restored and a user has acknowledges the fault by entering a valid access code.
External PSU Fault (15)	An external power supply fault signal triggers a Power output fault zone. The control unit deactivates the output when the zone has been restored and a user has acknowledges the fault by entering a valid access code.
Tamper (16)	The control unit detects tamper on any device; deactivates when tamper is reset.
Zone Omit (Setting) (17)	The user Omits a zone while setting the system. The output deactivates when the control unit restores the zone.
Zone Omit (System) (18)	(Operates only when DD243 is enabled.) In the event of an unconfirmed alarm, the system will rearm itself when the confirmation timer expires. If the zone that caused the unconfirmed alarm is still active at the time of the rearm, the control unit will omit that zone and activate the output. The control unit will restore the zone and output when a user or engineer resets the system.
General Fault (19)	There is any event that causes an alert indication on the keypad.
ATS Test (20)	(This output type appears only for Plug-by outputs.) The line fault input signal goes to 12V. The operation of the Line Fault input and the ATS test output must comply with the requirements of BSIA form 175.
Siren (21)	The control unit starts a full alarm, a panic alarm or a fire alarm (the siren has a distinctive tone during a fire alarm). The control unit deactivates this output at the end of the siren time.

Type:	Active when:
Strobe (22)	The control unit starts a Full alarm, panic alarm or fire alarm. The output remains active until the user disarms the system.
Entry Exit Follow (23)	The entry or exit time starts and deactivates at the end of the entry/exit time, or if the entry/exit time is terminated. The output can be used for a separate entry/exit buzzer. Note that the output does not operate if the exit mode is silent set or instant set.
Armed (24)	The system is full or part set.
PIR Set Latch (25)	The system is set. Inactive when the system is unset or an alarm condition occurs. The output is active for one second when a reset is performed or when the control unit leaves installer mode.
Shock Sensor Reset (26)	Exit time starts. The output remains active for five seconds. Use this output to reset shock sensors (for example, the "Viper").
Walk Test (27)	A user starts Installer- or User Walk Tests. Also active during the time between silencing and resetting the system. This output can be used on movement detectors that are able to switch off the Walk Test lamp in any state other than a Walk Test.
Smoke Sensor Reset (28)	This output is active (OV) all the time except when a user acknowledges a fire alarm: after which the control unit deactivates the output for three seconds. This output type is designed to be connected to low-voltage smoke detector reset terminals.
24 Hour Alarm (29)	The control unit starts a 24 hour alarm.
Setting Complete (30)	The control unit finishes setting. Active for 10 seconds.
Unset Complete (31)	Someone unsets the system or disarms it after an alarm. The output is active for 10 seconds.

Type:	Active when:
Full Set Ready (32)	None of the detectors are reporting "alarm" signals.
Full Set (33)	The system is full set. If the system is partitioned, then the output is active only when all assigned partitions are Full Set.
Part Set (34)	The system is part set.
Part Set B (35)	Setting Part Set B. Deactivated on unsetting Part Set B. (Available only in a Part Setting system)
Part Set C (36)	Setting Part Set C. Deactivated on unsetting Part Set C. (Available only in a Part Setting system)
Part Set D (37)	Setting Part Set D. Deactivated on unsetting Part Set D. (Available only in a Part Setting system)
Set Fail (38)	A set command fails. Remains active until the user acknowledges the set fail.
Zone Follow (39)	A specified zone has been triggered. If you select this type for a zone then the display shows an extra "Follow" option for the output. Use this option to select the zone you wish the output to follow. (You can follow a "not used" zone.)
Zone Alarm (40)	The selected zone causes an alarm. Deactivated when the alarm has been reset. When programming this output type the installer can select a specific zone for the output to follow. (You can follow a "not used" zone.)
User Defined (41)	The user switches the output on or off from the keypad, or a remote control. Assign this output type to any outputs that you want the user to control.

Exit Modes

When choosing an exit mode for a partition or a part set, the available options are:

Final Door Set Use this option to complete setting the system by closing a door fitted with a Final Exit zone detector. Note that the exit time is infinite in this option.

The system allows a seven second settling time after closing a final door.

Note: Do not try to make a PIR zone act as a Final Exit. Radio PIR detectors have a "lock out" period after each activation in order to conserve battery power. When you set (or part set) the system a PIR may still be in lockout, during which it cannot send a signal to complete the setting process.

Timed Set Use this option to make the system set after a delay. Use the Exit time menu to choose the delay.

Instant Set The system sets immediately and without any tones.

Silent Set The system sets after the exit time programmed in the Entry/Exit Time menu but does not give any exit tones. When the system sets the keypad gives a double beep.

The keypad gives a double beep confirmation tone at the end of all setting modes.

7. Maintenance

The control unit should be inspected once per year. At each inspection:

Check the control unit for obvious signs of damage to the case or its lid.

Check the action of the back tamper.

Check the condition of the control unit standby battery.

Check the cabling to the keypad(s) for signs of damage or wear.

Check the keypads for obvious signs of damage.

Test the action of all buttons on all keypads.

Clean the keypad surface and display. To clean the keypad wipe the surface with a clean soft dry cloth. Do not use water, solvents or any proprietary cleaning materials.

Monitor the signal strength and battery condition of all detectors, radio keypads, remote controls, PAs and radio sounders. Test each device. Replace batteries as recommended by the manufacturer's instructions.

Gently clean the lenses of any PIRs with a clean, soft dry cloth. Do not use water, solvents or any proprietary cleaning materials.

Walk test all detectors.

Test any external sounders and strobes.

8. Technical Specification

General

Product name	i-on40.
Product Description	40 zone hybrid endstation with remote keypads.
Manufacturer	Cooper Security Ltd.
Environmental Class	Class II.
Operating temperature	Tested -10 to +55°C.
Humidity	0 to 93% RH, non-condensing.
Case material	ABS LG-AF342.

Dimensions:

Control unit	384 x 245 x 94, mm HxWxD.
Keypad	115 x 156 x 34, mm HxWxD

Weight:

Control unit	2.2 kg (without stand-by battery).
Keypad	0.26 kg

Capacities

Zones	16 wired, 24 radio
Keypads	4 wired, 4 radio
Outputs	16 wired (comprising two voltage free contacts, 14 transistorised of which 12 are provided on separate wiring harnesses). 8 radio output channels.
Internal Clock	±10 minutes over one year (depending on the accuracy of the mains supply frequency).
Remote controls	50
Panic Alarms	50
External Radio Sirens	4
Plug on communication modules	One only
WAMS	4
Log capacity	Up to 1,000 events: 750 mandatory events, 250 non-mandatory. Stored in EEPROM memory, available for at least 10 years without power.

Security

Security Grade	Grade 2.
Radio detector differs	16,777,214 (2 ²⁴ -2).
Radio Supervision	Programmable.
Number of access codes	50 plus installer
Access code differs	10,000 differs. 4 digit codes, all four digits may be any number 0 to 9.
Code blocking	Blocked for 90s after 10 incorrect codes (or prox tags) in series. Blocked for a further 90s after each additional incorrect code or prox tag, until next correct code or prox tag entered.
Proximity tag differs	4,294,967,296 (2 ³²)

Radio

Radio Section	Operating frequency 868.6625MHz Narrowband. EN 300 220-3. EN 300 330-2
Transmitter range	The range of the transmitters compatible with this control unit depends on the environment in which they are installed. As a guideline, most transmitters will work up 200m range in free space conditions.

Power Supply

Integrated power supply. Monitoring includes mains fail, battery low voltage, aux output low voltage, battery failure.

Power supply type:	A
Mains power supply requirements:	230VAC +10%/-15%, 170mA max, 50Hz
Total power supply capacity:	1.5A
Aux power supply:	1.1A capability
14.4V output:	300mA capability
Comms power supply:	500mA capability
Keypad bus power supply rated output:	500mA capability

Note: Under EN50131-6 the maximum total load that can be drawn from these outputs

i-on40

is 270mA i.e. the aux current that can be supplied for 12hrs by a 7 A-h battery under normal operating conditions.

EN50131-6 ratings:

PSU rated output:	270mA max
Independent power outputs (Normal operating conditions):	Total not to exceed 270mA for 7 Ah battery
CIE power requirement:	130mA min. 220mA max
Keypad power requirement:	30mA (backlight off) 45mA (backlight on) 65mA (backlight on)
Battery changing requirement:	270mA
Communicator power requirement:	20mA quiescent 50mA max
12V Aux output voltage range:	9±0.5V to 13.8V
14.4V output voltage range:	9±0.5V to 14.7V
Max p-to-p ripple voltage:	0.5V
Standby Battery:	12V, 7Ah sealed lead acid.
Max recharge time to 80% capacity:	Less than 72 hours.
'Low battery' fault at:	< 12V
Aux power output fault at:	< 9V
Deep discharge protection at:	9±0.5V
Serviceable components:	Mains fuse: 250mA (T)
Standby time:	See "Power Availability" on page 4.

Electromagnetic Compatibility

Immunity	Conforms to EN50130-4.
Emissions	Conforms to EN61000-6-3.

Outputs

O/P 1 - 2	Voltage free, single pole relay contacts rated 24VDC @ 1A.
O/P 3 - 4	Open collector transistor, +12VDC when inactive, 0V when active. 500mA max.
O/P 5 - 16	Open collector transistor +12VDC when inactive, 0V when active, 50mA max.
LS	Min impedance 16 Ohm,

(loudspeaker)	current consumption from 12VAux = 280mA in alarm.
---------------	---

Fuses

The control unit has a replaceable T250mA mains fuse.

Electrical Safety

Conforms to EN60950-1.

Other

If you wish to connect the i-on40 control unit to a PC using either the Ethernet or the USB port then make sure that the cables have the following specifications:

Ethernet	Cat5e patch cable, RJ45 male plugs at each end, suitable for 10/100Base-T.
USB	Mini-B plug for control unit end, USB-A for PC end. Max length 3m.

Compliance Statements

This product is suitable for use in systems designed to comply with PD 6662: 2004 at grade 2 and environmental class II.

This product complies with the requirements of EN50131-3 at grade 2 and environmental class II.

This product complies with the requirements of EN50131-6:2008 at grade 2 and environmental class II.

When fitted with an i-sd02 this equipment is compliant with EN 50136-1. It allows the alarm transmission system to meet the performance requirements of EN 50131-1:2006 ATS 2 provided that:

- It is installed in accordance with the installation instructions.
- The connected PSTN is functioning normally.

When fitted with an i-sd02 this product provides options A, B and C at Grade 2 as noted in Table 10 of EN50131-1:2006+A1:2009.

If the installer selects a non-compliant configuration then they must remove or adjust compliance labelling

Third party approval carried out by Telefication

Compatible Equipment

706rEUR-00	Two button PA/tilt switch transmitter	770rEUR-00	Wireless Accessory Module
710rEUR-00	Two button PA	771rEUR-00	Info Module
713rEUR-00	Pet tolerant PIR	08844EUR-00	GPRS module
714rEUR-00	PIR Transmitter (Small case)	08750EUR-00	Ethernet module
720rEUR-00	Smoke Detector Transmitter	9040UK-00	Speaker boxed
726rEUR-50	Long range hand held PA	i-fb01	Four button remote control
726rEUR-60	Short range hand held PA	i-kp01	Keypad
734rEUR-00/01	CC/FSL Door Contact Transmitter (white)	i-rc01	Relay Card
734rEUR-05/06	CC/FSL Door Contact Transmitter (brown)	i-rk01	Radio Keypad
738rEUR-00/04	Spyder shock sensor (white/brown)	i-sd02	PSTN Communication module with speech dialling
739rEUR-25	Sentrol glass break detector (no tamper)	i-dig02	PSTN Communication (ARC only).
760ES	External Wireless sounder	i-gsm02	GSM communications module
762rEUR-00	Two Channel Receiver	xcelr	Radio PIR
768rEUR-50	Eight Channel Receiver	xcelrpt	Pet tolerant radio PIR
		xcelw	Wired PIR
		xcelwpt	Pet tolerant wired PIR

www.coopersecurity.co.uk
 Product Support (UK) Tel: +44 (0) 1594 541979.
 Available between:
 08:15-12:30 and 13:00-17:00 Monday to Friday.
 Product Support Fax: (01594) 545401
 Part Number 12003623